



Type	LSREP5025TE	LSREP5032TE
A(mm)	3440	4040
B	2770	3370
C	4875	5475
D	5980	6580

PRESSURE AIR CONNECTION

Pressure air is connected by tube PU 8x1,25 on the socket connection, pos. 9. Maximal recommended pressure is 6 bars. Setting of air pressure on input regulator is 3 bars without cross folder. Air consumption of particular machines, see chart below.

LEGEND:

- 1. Ironing machine
- 2. Cross folder
- 3. Stacker
- 4. Removal conveyer
- 5. Main power supply
- 6. Pressure air connector of the cross folder
- 7. Connector for control cable of the cross folder
- 8. Power supply connector of the cross folder
- 9. Pressure air supply
- 10. Steam supply (version "S")
- 11. Gas supply (version "G")
- 12. Condense drain (version "S")

AIR CONSUMPTION CHART

Machine type	LSREP5025TE	LSREP5032TE
Ironer (litre/min)	63,32	73,12
Cross folder	36,8	36,8
Stacker	22,5	22,5
TOTAL (litre/min)	122,5	132,42

	LSREP5025TE	Date	10.06.02	No.	03-105-1.2
	LSREP5032TE	Author	T.Ř.	Index	
		CROSSFOLDER&STACKER CONVEYER			